



## LASER LOCK YOUR PUTTING!

### Setup Instructions for the Pin Point Laser



#### Step 1:

Position the trigger unit on the back side of the putter grip near where your lowest finger would touch the button, tighten with velcro strap.

#### Step 2:

Peel the protective plastic strip from the sticky pads of the laser unit - **Save in the case and reapply after each use.**

#### Step 3:

Look for the putter's center line through the top window of the Pin Point Laser. Match the line on the top of the laser with the line on the putter or approximate center of the head.

#### Step 4:

Rest the shoulder of the unit on the top of the putter blade and slowly tilt the laser forward so the sticky pads adhere to the face of the putter.

#### Step 5:

Gather the excess wire against the shaft and utilize the twist tie to secure it.

### Maintaining Your Pin Point Laser

When removing the Laser from the putter, always use the provided plastic protective strip to cover the sticky surface. If the adhesive pads begin to lose stickiness, simply wipe with a wet cloth and they will regain their tack.

To replace the battery, simply remove the screws in the underside of the trigger unit.

### Quick Start Guide for the Pin Point Laser



**Step 1:** Place all three targets in different positions on the putting surface securing them with tees. If putting indoors, place a ball on the backside of the target to anchor it.

**Step 2:** When in putting position, look through the Pin Point Laser window to see the center line on the back flange of the putter, if applicable.

**Step 3:** Place your lowest finger on the button of the trigger. Aim the putter toward the target and push the trigger.

**Step 4:** Make note of any corrections which need to be made in alignment, move from target to target to test your alignment.

**See additional instructions and videos at [EyeLineGolf.com](http://EyeLineGolf.com)**